

Work Order ID 81335

81335

Page 1

March-13-12 1:32:03 PM

Item ID: D350-766-013

Accept

N900040100

Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Interior Trim, Ceiling

Start Date: 13/03/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 27/03/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: MLJ

Date: 12/03/13

Tooling:

Date:

QC:

Date:

SPC (Y/N):

Date:

Run Start ***NR1***

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
IIN D350-766	Rev C

100

100

DC

Document Control

DOCUMENT CONTROL

0.00

Memo

0.00

Photocopy bluefile & type labels per PPP D350-766-013 CHG002

in Sidelit

MLJ 12-4-17

110

110

Packaging

Packaging

Pick Kit

0.00

Memo

0.00

444/17

120

120

QC

Quality Control

QC4- 100% Inspect kits for completeness

0.00

Memo

0.00

Sidelit

QC

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 81335

81335

Page 2

March-13-12 1:32:03 PM

Item ID: D350-766-013

Accept

N900040100

Setup Start ***NS1***

Revision ID:

Item Name: Interior Trim, Ceiling

Stop ***NS2***

Start Date: 13/03/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 27/03/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____
QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Run Start ***NR1***
Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00							
130									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D350-766-013 Location: _____ PPP Rev: <u>B</u>								
140	QC21- Final Inspection - Work Order Release	0.00							
140									
QC	Memo	0.00							
Quality Control									

/X

SP

12-04-17

12/4/19

12-04-18

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

March-13-12 1:32:07 PM

81335

D350-766-013

Required Qty: 1.00

Comments: IPP REV A NEW ISSUE 08/04/08 DL verified by:DD

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D3656-1		Manufactured	No			110	Each	0.0000	1	1			
D3656-1													
PANEL									**	81 350			
D3656-3		Manufactured	No			110	Each	0.0000	1	1			
D3656-3													
PANEL									**	81 351			
AN526-1032R9		Purchased	No			110	Each	48.0000	15	15			
AN526-1032R9													
Screw									**				
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				ST348		48				114 382			
				114382		4							
				116900		4							
				117395		40				117395			
CCR264SS3-3		Purchased	No			110	Each	693.0000	30	30			
CCR264SS3-3													
Cherry Rivet									**				
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				ST331		693							
				113973		2							
				117849		125							
				119017		566				119017			

Dart Aerospace Ltd

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____
 Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

March-13-12 1:32:07 PM

Page 2

Work Order ID: 81335

81335

Parent Item: D350-766-013

D350-766-013

Parent Item Name: Interior Trim, Ceiling

Start Date: 13/03/2012

Required Date: 27/03/2012

Start Qty: 1.00

Required Qty: 1.00

MS21059L3

Purchased

No

110

Each

386.0000

15 / 15

MS21059L3

Nut Plate

Handwritten signature and initials

Location

Loc Qty

Loc Code

ST301

28

118614

8

119546

20

ST302

358

120308

158

120833

100

121011

100

120833

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

4.0 WEIGHT AND BALANCE

The following is the weight increase associated with the Interior Trim Kits. Be sure to subtract the weight of any parts removed.

Installation	Weight	LATERAL		LONGITUDINAL	
		Arm	Moment	Arm	Moment
D350-766-011 Interior Trim Kit (Aft Bulkhead Trim Kit)	13.2 lb 6.0 kg	0 in 0 m	0 in-lb 0 m-kg	113 in 2.87 m	1492 in-lb 17.2 m-kg
D350-766-013 Interior Trim Kit (Ceiling Trim Kit)	11.0 lb 5.0 kg	0 in 0 m	0 in-lb 0 m-kg	91 in 2.31 m	1001 in-lb 11.6 m-kg
D350-766-015 Interior Trim Kit (Canopy Post Trim Kit)	5.2 lb 2.4 kg	0 in 0 m	0 in-lb 0 m-kg	42 in 1.07 m	218 in-lb 2.6 m-kg
D350-766-021 Interior Protector Kit (Aft Baggage Protector Kit)	14.3 lb 6.5 kg	2.77 in 0.07 m	39.6 in-kg 0.46 m-kg	168 in 4.27 m	2402 in-lb 27.8 m-kg

5.0 PARTS LIST

Qty -011	Qty -013	Qty -015	Qty -021	Part Number	Description
X				D350-766-011	INTERIOR TRIM KIT (AFT BULKHEAD TRIM KIT)
	X			D350-766-013	INTERIOR TRIM KIT (CEILING TRIM KIT)
		X		D350-766-015	INTERIOR TRIM KIT (CANOPY POST TRIM KIT)
			X	D350-766-021	INTERIOR PROTECTOR KIT (AFT BAGGAGE PROTECTOR KIT)
1				D3655-1	PANEL
1				D3655-3	PANEL
	1			D3656-1	PANEL
	1			D3656-3	PANEL
			1	D3889-041	PANEL, FLOOR
			1	D3890-041	PANEL, WALL
			1	D3891-041	PANEL, FWD LH
			1	D3891-042	PANEL, FWD RH
			1	D3944-1	PLACARD
			4	D3945-041	BRACKET
		1		D3946-1	PANEL, CENTER POST
		1		D3947-1	PANEL, UPPER LH POST
		1		D3947-2	PANEL, UPPER RH POST
		1		D3947-3	PANEL, LOWER LH POST
		1		D3947-4	PANEL, LOWER RH POST
			3	D3948-041	PLATE, ANCHOR
			4	D3948-043	PLATE, ANCHOR
			14	AN525-10R7	SCREW
			4	AN525-10R9	SCREW
2				AN526-1032R12	SCREW
2				AN526-1032R20	SCREW
	15			AN526-1032R9	SCREW
			8	CCR264SS3-2	RIVET
	30			CCR264SS3-3	RIVET
8				CCR274SS3-4	RIVET
			8	CR3213-4-02	RIVET (OR M7885/2-4-02)
			12	CR3523-4-02	RIVET (OR M7885/4-4-02)
			16	CR3523-4-03	RIVET (OR M7885/4-4-03)
4	15		4	MS21059L3	NUTPLATE (OR MS21059-3)

• COPYRIGHT © 2008 BY DART AEROSPACE LTD. •
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: C
Date: 09.06.08